

## Note:

Jet pump 1 is connected to A swim jet;

Jet pump 2 is connected to C swim jet;

The C swim jet is connected in series with the C1 jets;

Jet pump 3 is connected to B swim jet;

The B swim jet is connected in series with the B1 jets;

The circulation pump is connected to the Group D water distributor;

Group D water dispenser is connected to D1 jets, fountain, and UV sterilizer;

E air valve is connected to the A swim jet;

F air valve is connected to the B and C swim jets;

H air valve is connected to the B1, C1 and D1 jets;

The fountain is controlled by water inlet switches J and K;

J water inlet switch controls J1, J2, J3 fountains;

K water inlet switch controls K1, K2, K3 fountains;

3pcs jet pump+1pc circulation pump

ZR7861 Spa Front View

